

ECOMAX 702 UTENSIL WASHER



The ecomax 702 Utensil Washer offers the best wash result for hard baked in dirt. Perfect for utensils like pots, pans, trays or boxes.

Utensil Washer ecomax 702

Cycle times*	120/360 sec
Capacity per hour*	up to 30 cycles
Wash/rinse temperature	60 – 65°C / min 82°C
Tank capacity	80 I
Fresh water consumption/cycle	4.5 I
Wash pump	2.9 kW
Heating booster/tank	9 kW / 3.3 kW
Total loading	12 kW
Rated voltage	400 V / 50 hz / 3N
Width/Depth/Height	780/945/1,765 mm
Loading height	630 mm
Rack size	600 x 760 mm

*hot water connection

Connection to cold water or reduced voltage can extend the heating time and the program runtime. We recommend an external water softener for feed water hardness above 3°dH.The installation of machines with integrated water softener requires a back flow safety device (at site) according to DVGW-DIN 1988. Line pressure required: 0,5 to 10 bar

PRODUCT ADVANTAGES

- Rotating top and bottom wash system to distribute the wash water evenly over the dishes
- Deep-drawn wash tank bottom, no hygiene problems with corners and edges
- Thermostop-function for guaranteed rinse temperatures
- Removal of wash and rinse arms without any tools
- Easy access to all parts
- Flat surface of control panel
- Loading of high trays and pots: up to 630 mm loading height
- 150 mm floor clearance
- Electronic control
- Made completely out of stainless steel
- Tank covered with strainer made of stainless steel

STANDARD EQUIPMENT

- Heater with thermostat control
- Pressure pump
- Electric cable, flexible water supply hose and drain hose



